

FILTERING CARTRIDGES - CLEANING



CARTRIDGES CLEANING

REMOVE THE CARTRIDGE AND RINSE IT WITH COLD WATER, COUNTER FLOW IF POSSIBLE, NAMELY FROM INSIDE THE CARTRIDGE OUTWARDS. BATH THE CARTRIDGE IN THE SOLUTION MADE WITH WATER AND A CHLORIDE DETERGENT, OR WATER AND ACETIC ACID.

LET IT DRY VERY WELL AND NEVER PLACE IT IN CLOSED PLASTIC BAGS OR CONTAINERS.



STAINLESS STEEL CARTRIDGES CLEANING

TAKE THE FILTERING CARTRIDGE OFF THE FILTER HOLDER AND USE THE FILTER HOLDER AS A CONTAINER. BATH THE CARTRIDGE IN HOT WATER AND SODA, OR WATER AND PERACETIC ACID (IN A 2X1000 CONCENTRATION).

THEN, CAREFULLY WASH IT WITH A SOFT BRUSH, TAKING CARE OF NOT HARMING THE FILTERING NET. REPEAT THE WASH PROCESS A SECOND TIME IF NECESSARY. RINSE ABUNDANTLY THE CARTRIDGE.